

## New Kiosk Installation

### STEP 1

**To access the floor of the kiosk (to install anchor bolts), first remove the Floor Sheet and Weigh Plate from the kiosk.**

- Remove the Floor Sheet first by lifting it near the front of the kiosk, raise it over the rivets (along the back wall), and orient the floor sheet vertically
- Rotate slightly to fit through the door.
- Remove the Weigh Plate from the kiosk, be careful with the cable when removing it.

### STEP 2

**Install the kiosk (see 'Installation Instructions' sheet for images)**

- Mark holes on the floor where the kiosk will be anchored
- Move kiosk aside and drill anchor bolt holes
- Install anchors
- Move kiosk back where it will sit
- Anchor the kiosk to the ground with included hardware

### STEP 3

**Plug in the cable from the Power Supply into the bottom side of the Control Module**

### STEP 4

**Close/Lock Access door on kiosk: the KMS is ready to use!**

- The KMS can be accessed/managed via the portal at: [portal.amrxgroup.com](http://portal.amrxgroup.com)