

New Kiosk Installation

STEP 1

To access the floor of the kiosk (to install anchor bolts), first remove the Floor Sheet and Weigh Plate from the kiosk.

- Remove the Floor Sheet first by lifting it near the front of the kiosk, raise it over the rivets (along the back wall), and orient the floor sheet vertically
- Rotate slightly to fit through the door.
- Remove the Weigh Plate from the kiosk, be careful with the cable when removing it.

STEP 2

Install the kiosk (see 'Installation Instructions' sheet for images)

- Mark holes on the floor where the kiosk will be anchored
- Move kiosk aside and drill anchor bolt holes
- Install anchors
- Move kiosk back where it will sit
- Anchor the kiosk to the ground with included hardware

STEP 3

Install the Weigh Plate and Floor Sheet in the kiosk

- Ensure floor of kiosk is clean before installing Weigh Plate. We strongly suggest vacuuming out the floor before installation as any debris could interfere with accurate weight measurements. Avoid damaging the cable when installing the floor sheet.
- When installing the Floor Sheet on top of the Weigh Plate, ensure cable rests in the rear-left corner of the kiosk so the Floor Sheet easily installs

STEP 4

Plug Weigh Plate (Ethernet cable end) into the Control Module

STEP 5

Plug in the cable from the Power Supply into the bottom side of the Control Module

STEP 6

Close/Lock Access door on kiosk: the KMS is ready to use!

- The KMS can be accessed/managed via the portal at:
portal.amrxgroup.com